
Fresh oil
float sensor
Fuel rail
Fuel injector
Fuel pump
Fresh oil tank
ECU
Fuel tank
Fresh oil supply to the
CORS Convertor
Engine Electronic
Control Unit (ECU)
Reconditioned or fresh oil from
CORS Convertor to the oil pan
CONVERTOR
CORS Convertor
Fuel line to fuel pump
Fuel and reconditioned used oil
Oil from oil pan to CORS Convertor
Engine oil
Reconditioned used oil to
be burned in combustion
Oil sensors assembly